## **SunSniffer Technology**

## SunSniffer SENSOR

Version H






The heart of the SunSniffer technology, the Sensor is deployed for module-level monitoring in solar panels. Installed in the junction box, it assolves the function of telemetry data collection and transmission:

- voltage (V);
- temperature (t°C);
- solar panel serial number.



Picture 2. SunSniffer Sensor - example of positioning in junction box



 ${\bf Picture}~{\bf 3.}~{\bf Sun} \\ {\bf Sniffer}~{\bf Technology}~{\bf Scheme}$ 





## INSTALLATION:


The sensor is easily installed:

Red wire has to be connected to module + terminal

Black wire has to be connected to module - terminal.


## **TECHNICAL SPECIFICATIONS:**

Dimensions (L x W x H)	38.0 x 12.5 x 4 mm	
Working voltage	10 ~ 45± 0.2 V	
Temperature	-40 ~ + 85 ± 2 °C	
Current consumption	≤10 mAmp	
Serial Number length (SN)	30 bit	
Data transmission interval (T), including:	$30 \pm 0.4 \text{ sec}$	
-Temperature transmission interval (T <sub>t°C</sub> )	4 ± 0.4 min	
- SP full serial number transmission interval (Tsnfull)	4± 0.4 min	
- Voltage transmission interval (Tv)	$30 \pm 0.4 \text{ sec}$	



Picture 4. Sensor technical drawing and dimensions

The SunSniffer sensor transmits data with 30 seconds interval. There are three types of data sent: 1) Module full serial number SN; 2) Module voltage V; 3) Module Temperature t°C. The sequence is repeated every 4 minutes. Please refer to data packet sequence below.



© SunSniffer GmbH & Co. KG. Specifications in this datasheet are subject to change without notice.

SunSniffer GmbH & Co. KG Ludwig-Feuerbach-Str. 69 90489 Nürnberg Germany

